



WS 325

Reservdelar

Spare parts

Ersatzteile

Pieces de rechange


Piezas de repuesto


Ricambi


Peças sobresselente


No.	Pos.	Description	No.	Pos.	Description
501 37 17-01 501 37 19-01 501 37 21-01 501 37 22-01 504 05 86-02 504 09 95-01 504 09 95-02 531 11 30-01 531 11 30-02 531 11 30-07	AD B C C M C C A F	Saw carriage Cover plate feeding Pivoting arm Pivoting arm cover Husqvarna OIL 150 4 dl. Arm complete 1" Arm complete 60mm Lever complete Short feed handle compl Telescopic feed handle compl	531 11 91-73 531 11 91-79 531 11 91-81 531 11 91-83 531 11 91-84 531 11 91-98 531 11 91-99 531 11 92-00 531 11 92-02	B C EFGHJK FGL G CE EHJK G HJK G	Radial shaft seal BA 15x28x7 Radial shaft seal BASL 30x42x6 Washer 10,5x22 Washer 13x24x2 Spring pin 6x90 Sealing ring 1/2" Screw M6S 10x25 Screw M6S 10x30 Screw M6S 10x35 Screw M6S 12x25
531 11 30-10 531 11 30-11 531 11 30-13 531 11 30-20 531 11 30-21 531 11 30-27 531 11 30-37 531 11 30-57 531 11 30-62 531 11 30-78	G G G A A H F K K E	Track section 2,3m Track section 1,3m Coupling link Guide Wheel concentric Guide Wheel eccentric Flushcutting flange compl. Water hose with valve Blade guard 730 compl Blade guard 930 compl Shaftseal set scn 18x30x6 compl	531 11 92-03 531 11 92-07 531 11 92-09 531 11 92-11 531 11 92-13 531 11 92-14 531 11 92-18 531 11 92-20 531 11 92-32 531 11 92-38	CL L HJK HJK J C A B G	Screw M6S 12x30 Screw M6S 12x45 Screw M6S 5x16 Screw M6S 6x16 Screw M6S 6x22 Screw M6S 6x25 Screw M6S 8x25 Screw M6S 8x35 Screw M6S 6x14 Screw MC6S 6x120 din
531 11 31-12 531 11 31-25 531 11 31-27 531 11 31-38 531 11 31-40 531 11 31-41 531 11 31-42 531 11 31-43 531 11 31-44 531 11 31-45	E	Hydraulic motor Blade guard 930 flushcut Blade guard flush cut Mounting bracket std Mounting bracket us Blade guard 730 flush cut middle Blade guard 730 flush cut sect. Blade guard 730 flush cut sect. Blade guard 930 flush cut middle Blade guard 930 flush cut sect.	531 11 92-40 531 11 92-48 531 11 92-59 531 11 92-83 531 11 92-85 531 11 93-02 531 11 93-08 531 11 93-10 531 11 93-29	HJ F J C C AF C C E E	Screw MF6S 12x30 Cap nut M10 Guide screw MP6SS 6x35 O-ring 44,2x3 O-ring 49,0x1,6 Key 4x4x16 Key 6x6x16 Key 8x7x25 Radial shaft seal Support ring 17x21
531 11 31-46 531 11 31-94 531 11 33-40 531 11 80-49 531 11 80-50 531 11 81-08 531 11 81-16 531 11 82-00 531 11 82-36	J HJ L E E C C E C	Blade guard 930 flush cut sect. Flushcutting flange compl. 1" Locking clamp screw Quickcoupling 3/8" female Quickcoupling 3/8" male Valve on/off Magnetic plug Coupling Adapter Quickcoupling male	531 11 93-33 531 11 93-35 531 11 93-40 531 11 93-48 531 11 93-64 531 11 93-98 531 11 94-08 531 11 94-11 531 12 10-20	D HJK E HJK L A A HJ HJ C	V-ring VS 45 Wing nut WM8 Plug VSTI R1/2" Washer 6,4x22 Spring Screw MLC6S 4x8 Washer 12x18x1 Screw UF6S 5/16-18x5/8 Screw MC6S 12x70 Pivoting arm shaft
531 11 90-65 531 11 90-70 531 11 90-71 531 11 90-77 531 11 90-80 531 11 90-81 531 11 90-82 531 11 90-83 531 11 90-84	M F J BD F HJK A C A	Wrench 18mm Stop ring Toogle fastener Hook Spring 5860 Toogle fastener Hook Washer AS 1226 Washer AS 2035 Bearing AXK 1226	531 12 10-25 531 12 10-30 531 12 10-32 531 12 10-33 531 12 10-36 531 12 10-38 531 12 10-40 531 12 10-41 531 12 10-48	D D A A A A A A A F	Vorm gear Retaining washer Worm shaft Worm shaft Adjusting spindle Eccentric spindle Bearing washer Support plate Interlocking cover,right Handwheel shaft
531 11 90-85 531 11 90-90 531 11 90-91 531 11 90-94 531 11 90-96 531 11 90-98 531 11 90-99 531 11 91-01 531 11 91-02	CCFCDAAADA	Bearing AXK 2035 Rubber plug GL 24 Disc wheel crank Bearing K25x30x26 ZW Nut KM10 Nut KM3 Spring LBR 45 F Ball 6mm Lock Washer MB 10 Lock Washer MB 3	531 12 10-53 531 12 10-59 531 12 10-76 531 12 10-84 531 12 10-85 531 12 10-86 531 12 11-20 531 12 11-58 531 12 11-59 531 12 11-60	F C G G HJK D D	Extension pipe Bracket Sealing Washer Guide track section 870mm Guide track section 510mm Guide track section 420mm Bracket Shaft Spacer sleever Worm and pinion gear
531 11 91-03 531 11 91-05 531 11 91-06 531 11 91-11 531 11 91-63 531 11 91-65 531 11 91-66 531 11 91-70 531 11 91-71	A F C E A H J K C D D	Bearing NK 12/12 Ball 5mm Support sleeve Lever Shim 28x35x3,2 Blind rivet 4x12 Shim 40x47x1 Shim 42x52x1 Shim 68x80x0,27 Shim 68x80x1	531 12 11-61 531 12 11-64 531 12 12-08 531 12 12-33 531 12 12-35 531 12 12-36 531 12 12-37 531 12 12-38 531 12 12-40 531 12 12-41	A F G HJK HJK G G G	Interlocking cover,left Feeding rod Crank MT160 End plate Guide pin left Guide pin right Aluminium profile track 2,3m Aluminium profile track 1,3m Gear rack 2,3m Gear rack 1,3m


No.	Pos.	Description	No.	Pos.	Description
531 12 12-42 531 12 12-43 531 12 12-44 531 12 12-80 531 12 12-86 531 12 12-88 531 12 12-93 531 12 13-44 531 12 13-65 531 12 13-66	D D F E G G D E A J	Guide, right Guide, left Flexible shaft Tube screw Coupling link Clamping washer Spacer ring Support wacher Guide plate Support plate	723 53 29-01 725 23 74-51 725 23 82-51 725 24 69-51 725 25 46-51 725 53 68-01 725 53 70-01 725 53 74-01 725 53 78-01 725 53 78-01	B B C C AC CG A D	Screw MFS 5x16 Screw M6S 6x30 Screw M6S 6x60 Screw M6S 8x90 Screw M6S 12x70 Screw MC6S 6x16 Screw MC6S 6x20 Screw MC6S 6x30 Screw MC6S 6x35 Screw MC6S 6x40
531 12 13-70 531 12 13-71 531 12 13-72 531 12 13-73 531 12 13-86 531 12 13-92 531 12 13-93 531 12 14-06 531 12 14-07 531 12 14-10	A A A C C C C C HJ	Guide wheel bolt concentric Guide wheel bolt eccentric Guide wheel Nut Blade shaft Blade flange inner Blade flange outer Cap Guide sleeve Flushcutting flange	725 54 51-01 725 62 91-51 725 63 66-51 725 63 68-51 725 64 49-51 728 73 60-05 728 84 43-01 729 64 12-01 731 23 20-01 731 43 20-01	L A ACD HJ CF B D HJK A	Screw MC6S 8x20 Screw MF6S 4x12 Screw MF6S 6x12 Screw MF6S 6x16 Screw MF6S 8x16 Stop screw S6SS 6x6 Stop screw SK6SS 8x8 Screw ST 4,8x16 Nut M6M M10 Nut ML6M M10 low
531 12 14-11 531 12 14-19 531 12 14-20 531 12 14-49 531 12 14-51 531 12 14-51 531 12 14-53 531 12 14-54 531 12 14-68	C HJK C C C C C C HJK	Sealing cover Hook plate Nut rod Running shaft Axial washer Running wheel Blade wheel Primary shaft Spacer ring Spacer ring	732 25 16-01 734 11 35-71 734 11 52-01 E 734 11 63-01 735 31 28-10 735 31 30-10 738 21 06-00 738 21 10-04 738 22 02-24 738 22 04-15	CL J BCGHJKI AB B E C D AD C	Nut M6 Nylock Washer 4,3x8 Washer 6,4x12 Washer 8,4x16 Seeger circlip SGH 16 Seeger circlip SGH 30 Bearing 6006 Bearing 6010-2RS1 Bearing 6202-R2S1 C2 Bearing 6204
531 12 14-71 531 12 14-97 531 12 14-99 531 12 15-04 531 12 15-05 531 12 15-06 531 12 15-07 531 12 15-12 531 12 15-13 531 12 15-24	C JK HK A D A A D E	Water block T-strut T-strut Guide plate Feeding cover Feeding cover Bearing cover Stop head Key Sealing cone	738 23 04-30 740 38 15-01 740 42 18-00 740 42 22-00 740 43 06-00 740 43 07-00 740 43 11-00 740 43 12-00 740 43 14-00 740 44 04-00	C C C C G E C E AE	Bearing 6304 Sealing ring M8 O-ring 22,1x1,6 O-ring 32.1x1,6 O-ring 8,3x2,4 O-ring 9,3x2,4 O-ring 13,3x2,4 O-ring 14,3x2,4 O-ring 16,3x2,4 O-ring 19,2x3
531 12 15-26 531 12 15-27 531 12 15-28 531 12 15-30 531 12 15-31 531 12 15-32 531 12 15-33 531 12 15-39 531 12 15-44 531 12 15-49	C C H C E E K K K K	Blade shaft 1" US/CAN Blade flange inner 1" US/CAN Flushcutting flange 1" US/CAN Water hose 6x1x52 Connecting block P Connecting block T Blade guard 730 middlesection Blade guard 730 section (blue) Blade guard 730 section (red) Blade guard 930 middle section	740 44 09-00 740 51 45-24	CE C	O-ring 32,2x3 Radial shaft seal
531 12 15-55 531 12 15-60 531 12 16-03 531 12 16-05 531 12 16-07 531 12 16-09 531 12 16-15 531 12 16-16 531 12 16-18 531 12 16-31	K K L L C C A L F	Blade guard 930 section (blue) Blade guard 930 section (red) Mounting bracket Locking clamp Nut stud Tubular shaft Blade flange outer 1" US/CAN Clamping sleeve Supporting bar Handle			
531 12 16-34 531 12 16-38 531 12 16-45 721 41 72-00 721 42 56-00 721 42 58-00 721 42 62-00 723 12 91-01 723 52 97-01 723 53 25-01	L A A F F J D HJK	Mounting bracket us Distance piece Lever Spring pin 2x24 Spring pin 4x20 Spring pin 4x25 Spring pin 4x32 Screw MCS 4x12 Screw MFS 4x25 Screw MFS 5x10			















WS 325 Telescopic feed handle compl 531 11 30-07



WS 325 Water hose 0,8 m with valve 531 11 30-37



